

EdgeFoil[®] Edge 1&2 Refill ReLOADING

Fig.1



REMOVING USED Foils from Cartridge:
 Place USED Cartridge on Clean Workbench
Cartridge Labels to your Left
 Use Extractor Tool As shown Left - Fig.1
 PULL OUT Removable RED Inserts as Shown.
 Retain RED Inserts to be reused
 Remove USED Foil-Cores from Cartridge Frame

Extractor Tool:

Screw Extractor Tool into Removable Red Insert As Shown - Fig 1
 Pull Out RED Inserts.
 Retain Red Inserts
 Remove USED Foil & Cores



printone^{UK}
 Tel: 01254 704330
www.EdgeFoil.co.uk

fig.3



Loading EdgeFoil[®] Refills:

Remove Refill Wrap - Fig.3
 Place Refill in Cartridge Frame - Foil to Right
 Take Up Core & Cartridge Labels - To the Left
 Foil to Bench - Cartridge Drive End away from you.

Spread Refill within Cartridge Frame.
 Re-Insert Retained RED Inserts - Fig.4

Remove & Retain Extractor Tool.

Wind On Foil to Take Up Core
 Remove Tension Pulls in Foil Spread ...
 Ensure NO Diagonal Creases in Foil

Reload complete - Ready to Print. - Change Cartridge Label if required

fig.4



We Make Edge[®]Cartridges REFILLABLE
 Resupplied to clients FREE!



RECYCLE

We Recycle used Foil Cores from USED Cartridges
 To be used again!
 Save a Large Boxfull - Ring Us - We'll Collect
REFILL NOT LANDFILL

